

Custom Functions overview

No.	Item	Initial setting (0)	1	2	3
C-00	Custom Function User	standard	User A	User B	User C
C-01	Steps of aperture, shutter speed, Exposure compensation	1/3 EV step	1/2EV step	1 EV step	
C-02	Data imprint	No	Data, Index	Index, Date	
C-03	Aperture setting after lens change	Previous aperture value	Open	Minimum	
C-04	Metered value display time	15 sec.	1:20 2:25 3:30	4:40 5:50 6:60 7:ON 8:5 9:10	
C-05	Range of exposure compensation	± 3EV	± 5EV		
C-06	External LCD backlight	set using backlightbutton			
C-07	Battery type	Alkaline/manganese (standard batteries)	NI-CD, Ni-MH		
C-08	Bracketing order	Normal-Under-Over	N-O-U	U-N-O	O-N-U
C-09	How to cancel Bracketing	Power OFF	Push bracketing button	Release after one session	
C-10	Bracketing variable	Shutter speed	Aperture value		
C-11	Front/Rear dial function exchange in manual mode	Front: Tv Rear :Av	Front:Av Rear :Tv		
C-12	Rear function dial enabled/disabled in P, Av, Tv	Enabled	Disabled		
C-13	Dial function direction	Right: decrease Left: increase	Right: increase Left: decrease		
C-14	Program PH/PL	PHigh/PLow	Av Shift	Tv Shift	
C-15	AEL & AFL function button exchange	Front: AFL Rear : AEL	Front: AEL Rear : AFL		
C-16	Shutter half-press function	AF operation	AF operation & AE Lock		
C-17	AEL function lock/unlock mode	Until turned off	Released after one shot	While the shutter button is pressed	
C-18	Focus Assist	On	Off		
C-19	AFL function lock mode	No AF operation before locking	AF operation before locking	1st push Lock 2nd push unlock	
C-20	M-mode in one push setting	Shutter speed shift	Aperture value shift		
C-21	Bulb exposure time setting	60 minutes	1:Off 2:1	3:2 4:4 5:8 6:15 7:30	
C-22	Bulb shutter release setting	While shutter button is pressed	start/stop exposure when shutter is pressed		
C-23	Shutter Speed in X mode	1/125	1/90(1/80)	1/60	1/45
C-24	Automatic sync speed	1/60 to 1/125	metered value (less than 1/125)		
C-25	TTL flash compensation mode	On	Off		
C-26	AF beam setting	On	Off		
C-27	Flash sync. timing	1st Curtain	2nd Curtain		
C-28	Copy custom function	No copy	Copy to A	Copy to B	Copy to C
C-29	Custom function	Keep settings	Reset settings		
C-30	Shutter release without film	No	Yes		
C-31	Auto film loading setting	Shutter button half-pressed	Closing rear cover		
C-32	Multiple exposure mode stop	Until multiple exposure button is pressed	multiple exposure number setting		
C-33	Custom function preference	Standard settings	User A	User B	User C
C-34	Clock/Calendar setting				
C-35	Index setting				
C-36	Firmware version	Press EV+/-, the top number is body firmware the below number is lensfirmare			

only relevant when using filmback